



### KAOKO™ THROTTLE STABILIZER KITS: CCF138

**For Models BMW  
R18 Cruiser (2020-)**  
With standard height bars having OEM chromed end weights

RSA Registered Designs  
No. A2007/00202 No. A2007/00205  
No. A2007/00203 No. A2007/00206  
No. A2007/00204 No. A2007/00207

Patents  
"U.S. Pat. No. US D593,462 S"  
"U.S. Pat. No. US D593,463 S"  
"U.S. Pat. No. US D593,464 S"


**Items Included in your kit**  
Kaoko bar-end Body • Friction Nut  
M12x90 Cap screw • 2mm Allen Key • Fitting Instructions

1




**A** — Throttle Sleeve  
(when bar-end is removed)

2



**A** — Kaoko bar-end body  
**B** — Kaoko M12x90 bolt  
**C** — OEM bar-end weight

3



**A** — Friction Nut & Grub Screw  
**B** — Kaoko bar-end Body  
**C** — OEM bar-end weight  
**D** — Kaoko M12x90 Screw

**DISCLAIMER: NO RESPONSIBILITY ACCEPTED FOR NON-ADHERENCE TO THESE INSTRUCTIONS**

#### KAOKO™ Safety Warning:

The KAOKO™ Throttle Stabilizer is an aftermarket accessory. Any misunderstood, abused or incorrectly installed motorcycle accessory is a safety hazard that could cause injury or death. It's the rider's responsibility to understand the operation and purpose for which the KAOKO™ Throttle Stabilizer is designed, namely, for cruising, only when safe to do so. At all other times the control should be disengaged. The KAOKO™ Throttle Stabilizers are to be used only by experienced and responsible riders. See reverse of page for full indemnity.

**Note:** An adjustment to throttle assembly position may be necessary to suit KAOKO™ Throttle Stabilizers. The throttle assembly position on aftermarket bars, and some OEM bars, is adjustable. The assembly can marginally be re-positioned along the handle bars slightly loosening the throttle assembly clamp screws, and then sliding the throttle assembly along the handle bars (left or right). Once done, firmly tighten the clamp screws to OEM torque specifications. This adjustment is generally not necessary.

### Fitting Instructions

#### Step 1

Remove the OEM end-weight using a TORX 55 for the central retaining screw (Note—the screw has been fitted with thread adhesive and is very firm on its removal). This will expose the handlebar and throttle sleeve as shown in **picture 1**.

#### Step 2

Place the Kaoko M12x90 screw through the OEM bar-end weight and Kaoko bar-end body as shown in **picture 2**.

#### Step 3

Secure the entire assembly into the handlebar with the M12x90 screw as shown in **picture 3**. It's recommended to use a mild thread locking adhesive on the threads of the screw.

**IMPORTANT**—The throttle should open and snap closed freely when correctly disengaged.

#### Step 4

Carefully set rotational resistance of the friction nut by tightening/loosening the grub screw by small adjustments using the 2mm allen key provided in the Kaoko Kit. Take care not to over tighten risking damage to threads. The nut should have fairly firm rotational resistance.

See under **Maintenance below**.

### Operating Instructions

The Friction Nut has a **left hand thread**. In readiness for engagement, the Friction Nut must be adjusted so that it makes light contact against the thrust washer.

**To Engage:** While rolling on the throttle, the Friction Nut can be gripped between the small finger and palm of hand. This action tightens the nut and provides sufficient friction to set the throttle to the desired opening.

*(The friction is such that the rider may still open and close the throttle. The throttle simply has a slight rotational stiffness.)*

**To Disengage:** While rolling off the throttle, grip the Friction Nut between small finger and palm of hand.

**VERY IMPORTANT!!** The throttle should open and snap closed freely when correctly disengaged.

**Note:** The Grub Screw needs to be set to provide the necessary resistance on the thread of the friction nut (only small adjustments need to be made as to not damage the friction nut threads). This may be adjusted periodically to take up wear.

**Maintenance:** Remove kit annually. Unscrew Friction Nut and brush clean threads with a mild soap. Apply petroleum jelly to threads and assemble. Adjust grub screw to desired operating resistance. (O-Ring cushion: 19.6mm I.D. x 2.4mm section — if replacement is required)